











A  M4x12mm x2	B  M5x12mm x2	C  M6x12mm x1	D  M8x12mm x1	E  Washer x1	F  Bobbin x1	G  M5x16mm x1	H  Allen key
---	--	--	--	---	---	--	--

Included
Inclus
Inbegriffen
Incluido

Also required
Également requis
Ebenfalls benötigt
También se requiere

Pozi-drive

Suitable fixings


1 EN Assemble to suit your TVs VESA pattern FR Assemblez en fonction du schéma VESA de votre TV DE Montage passend zur VESA-Bohrung Ihres Fernsehers ES Compatibilidad con interfaces de montaje VESA para su televisor

1

?

1

VESA 75 / 100

?

1

VESA 200 / 300 / 400 / 600

i

EN Wall Installation
FR À Installation murale
DE Wandinstallation
ES Instalación en pared

